



Cut on Dashed Line

Place face up on the front of your gameboy. Hold your gameboy up to the light and line up the A and B button holes from the back. Tape down with button holes lined up. Use center punch on X and Y guide marks. Drill Holes with 7/16" or 11mm drill Bit.